

Shingle Gooseneck Vent

OUTSTANDING PERFORMANCE

The only Gooseneck
Vent of its kind to pass
the Standard TAS
100 Wind-Driven
Rain Test



Features:

- ▶ High Quality & Durability -
Reduces customer call-backs.
- ▶ Internal baffle offers a third line
of defense against wind-driven rain.
- ▶ Promotes superior airflow and makes
it ideal for kitchen or bathroom exhausts.
- ▶ Interior louver panel captures any moisture
directing it to vent pan away from the attic.
- ▶ Suitable for any roof pitch from
3/12 to 12/12.
- ▶ Keeps insects and critters out.
- ▶ High Quality & Durability -
Reduces customer call-backs.

 **Not to be Used as a Laundry Vent.**

EXPAND YOUR ROOFING SYSTEM PERFORMANCE
PREVENT LEAKS • PROTECT PROPERTY • ASSURE VENTILATION

INSTALLATION INSTRUCTIONS

VALUE DRIVES EVERYTHING WE DO

Value drives everything we do. That's why we developed a comprehensive line of ventilation products that offer easy installation, remarkable building ventilation, lower utility costs, extended roof deck life, extreme durability, and outstanding warranties. Get more quality, more performance, and more value...from Marco Industries.™

EASY INSTALL

See our installation online at marcoindustries.com

1. When installing vents on an existing shingle roof: remove shingles immediately around sides and top of opening to provide space to install vent as per instructions below.
2. Shingle courses should be installed close to the deck opening so that the front flange of the vent completely covers exposed section of shingle.
3. Position the vent to cover the last course of shingles at the sides and bottom of the opening. Center the vent over the opening in the deck. Apply an industry approved sealant under front flange of vent.
4. Fasten side and top flanges securely with minimum 1.25" standard roofing nails spaced 4" on center and 1.5" from outer edge of flange.
5. Apply roof cement on side and top flanges. Completely cover flanges 2" beyond flange onto underlayment with 1/4" thick bed of plastic roof cement or equal.
6. Install shingles, cut to fit so flanges are completely covered. Press into place to ensure a complete bond of cement to the shingles. Fasten shingles with nails as per shingle manufacturer's instructions.

*Tip: Pre-cut shingles to fit prior to applying roof cement.
Then remove cut pieces, apply roof cement, and install shingles per above.*

SPECS:

Dimensions: Width 19-3/16" x Height 7 1/2"

Material: 26 - gauge galvalume

Codes & Standards: FL Building Code

Roof Pitch: Conforms to any pitch from 3/12 to 12/12

Color: Black, Weather Wood, Galvalume

Patents: Pending

Sizes: 4", 6" and 10"

Vent Hood: Mini louvers in lower portion of hood block water.

Interior Louver Panel: Acts as second water barrier.

Internal Baffle: Placed at the top of the vent pan, the internal baffle is the third line of defense against water intrusion.



X Not to be Used as a Laundry Vent.



1-800-800-8590 / Marcoindustries.com

MARCO INDUSTRIES™
Roofing Ventilation & Accessories