

150 Round Vent

A HIGHLY EFFICIENT AIR VENT

That offers 150 square inches of net free venting area, for use on larger roofs. The 150 will not rust, dent or break.



Features:

- ▶ Suitable for any pitch from 2/12 to 16/12.
- ▶ Higher NFA means fewer roof penetrations.
- ▶ Requires a square cut out which is easier to cut on a roof.
- ▶ No sharp edges - safer to handle.
- ▶ Comes in three colors: Black, Brown, and Weatherwood.
- ▶ Made of high impact Polypropylene with heat stabilizers and UV inhibitors throughout.
- ▶ 26" x 26" size - easy to install.
- ▶ Virtually indestructible. No flange bending or denting of dome.
- ▶ Green Product.

EXPAND YOUR ROOFING SYSTEM PERFORMANCE
PREVENT LEAKS • PROTECT PROPERTY • ASSURE VENTILATION

INSTALLATION INSTRUCTIONS

VALUE DRIVES EVERYTHING WE DO

Value drives everything we do. That's why we developed a comprehensive line of ventilation products that offer easy installation, remarkable building ventilation, lower utility costs, extended roof deck life, extreme durability, and outstanding warranties. Get more quality, more performance, and more value...from Marco Industries.™

EASY INSTALL

See our installation online at marcoindustries.com

1. Locate the roof vents on the rear or side of the house evenly spaced on the width of the roof.
2. Mark the location of all roof vents before cutting holes. Center the holes between the rafters down at least two feet (24") from the peak of the roof.
3. Holes should be cut 17½" High x 15½" Wide. 150 Round Vent box has a template for error proof installation. Using the template mark the outline for the hole on the roof. The hole in the roof cannot be larger than the hole in the bottom of the vent.
4. Shingle up until shingles cover the bottom of the hole. Cut the excess shingles away. Because shingles are part of a porous system applying an approved sealant around the edge of the hole is required.
5. The top of the 150 Round Vent has a molded in peak. Ensure that the vents are installed with the peak at the UP position.
6. Secure the vent base with a minimum of 8 galvanized nails. Nails should be a minimum of 1¼" long and must penetrate the vent, shingle, and decking. Secure a nail in the each corner of the vent flashing and along the middle of each side of the vent.
7. To seal the vent, use a plastic friendly roofing sealant. All nails must also receive a dab of sealant.
8. Shingle up and around the vent ensuring that the shingles butt up against the throat of the vent.
9. Pre-cut the top shingle to fit around the cricket of the vent and nail in place. Shingle up as normal to complete installation.

SPECS:

Dimensions: Width 26" x Length 26"x Height 6.97"

Patents: US Pat No. 7,544,124, US Pat No. 7,780,510, US Pat No. 10,415,252

Construction Details: With heat stabilizers and UV inhibitors throughout

Durability: Will not dent or rust, UL 2218: Class 4 Impact Resistance

Codes & Standards: TDI, FL Building Code, CSA

Roof Pitch: Conforms to any pitch from 2/12 to 16/12

Color: Black, Brown, Weather Wood

Material: No-break polypropylene

Vent Weight: 4.34 lbs per piec

Pack Unit of Measurement: 1 per carton



1-800-800-8590 / Marcoindustries.com

