

SSV Standing Seam Vent

SUPERIOR VENTILATION

The SSV is the only vent tested and proven to deliver 18 square inches of Net Free Area per linear foot. The added exclusive non-woven material won't break down over time and is reliable, and built to last. The pre-applied butyl tape makes installation quick and easy—so you can install the next SSV without missing a beat.

Features:

- ▶ Pre-cut lengths for a variety of different metal panels.
- ▶ Fast, easy installation.
- ▶ Exclusive Nonwoven, fabric won't deteriorate over time.
- ▶ Includes a strip of Marco's proprietary Weather-Tite™ non-woven material for superior protection against the elements.
- ▶ Pre-applied butyl tape and fastener holes.
- ▶ Built with long lasting quality and durability.
- ▶ Superior Net Free Area at 18 square inches per linear foot.
- ▶ Keeps moisture, insects and critters out.

EXPAND YOUR ROOFING SYSTEM PERFORMANCE
PREVENT LEAKS • PROTECT PROPERTY • ASSURE VENTILATION

INSTALLATION INSTRUCTIONS

VALUE DRIVES EVERYTHING WE DO

Value drives everything we do. That's why we developed a comprehensive line of ventilation products that offer easy installation, remarkable building ventilation, lower utility costs, extended roof deck life, extreme durability, and outstanding warranties. Get more quality, more performance, and more value...from Marco Industries.™

EASY INSTALL

See our installation online at marcoindustries.com



STEP 1: Snap a chalk line about one-eighth to one-sixteenth of an inch above the position where the ridge cap will be installed.




STEP 2: Peel away the backing from the butyl tape. Allow the over-stuffed foam to expand so it completely fills the gap between the top of the rib and the SSV. Align the SSV along the chalk line.



STEP 3: Secure the SSV using type 410 fasteners, ensuring at least one-half inch of penetration into the decking. Space the fasteners no more than three inches apart.



STEP 4: Apply sealant at the points where the SSV meets the panel ribs.



STEP 5: Install the open hem ridge cap by locking both bottom sides over the top and side of the SSV. Secure and finish installing the ridge cap by following the steel manufacturer's installation instructions and detail.



SPECS:

Height: 1", 1.5", 1.75", 2"

Length: Custom cut

Testing: Passed TAS-100(A)



1-800-800-8590 / Marcoindustries.com


Roofing Ventilation & Accessories